

## The installation instructions for the CONNECT-EZ Panel Anchor cover are very simple.

- 1) Remove all dirt, grease, lose concrete, etc. from an area 2" wide on the concrete panel surface around the entire exposed perimeter of the panel anchor drill cavity.
- 2) Trim the plastic panel anchor cover such that when installed the cover extends a minimum of 2" below the finished floor elevation. (The top of the cover should extend 1" above the top of the drill cavity.)
- 3) Apply a ¼" bead of good quality contact cement (F-26 by Leech, available from White-Cap) around the entire perimeter of the back side of the plastic cover.
- 4) Slide the cover into the exposed drill cavity, bottom end first, until the bottom of the cover is 2" below finished floor elevation.
- 5) Gently, but firmly, press the cover into the drill cavity until the cover is in contact with the concrete panel surface.
- 6) Wipe any excess contact cement from the surface of the panel and the cover.
- 7) Paint as required (see below)















F-26 by Leech, available from White-Cap

Please call if there are further questions.